





# Boston Electronic Tamper

## Charging

Using a phone charging pad, invert tamp and place in charge pad until charge.



## Turning On

Invert the tamper, on the underside you will see a small white switch, depress to turn on



## Adjusting

By pressing the buttons on the top of the tamper the pressure can be increased or decreased.

Left button = Will lower the number and decrease the pressure

Right button = Will raise the number and increase the pressure



Recommended start position 15



# Boston Electronic Tamper



PERFORM THIS AT LEAST  
ONCE A DAY



THIS CLEANING PROCEDURE  
TAKES APPROX. 5 MINUTES

## Cleaning

Press and hold the right button for 3 Sec, until you see the screen change, then release. Press once more to lower head, Then Clean with a soft brush. To retract head press once again, then press and hold 3 sec to exit cleaning mode.

[https://youtu.be/qnHACSq4ITs?list=TLGG1Qt1Fc7\\_fmngwMzA1MjAyMg](https://youtu.be/qnHACSq4ITs?list=TLGG1Qt1Fc7_fmngwMzA1MjAyMg)



## Additional setting

To access the menus, press and hold Left button for 3 sec. Also, to progress to the next option



### CALIBRATION MODE

Detach Portafilter "Single click left button"  
Attach Portafilter  
Set Hysteresis  
Default 70 (Range 0 <-> 100)

### DWELLING TIME

Set Dwelling time  
Default = 0s (Range 0, 1 & 2Sec)

This setting sets the tamp time, head will extend the hold for the set time

### TAMPER SPEED

Set Tamper Speed  
Default = Fast (Range Low, Medium & Fast)

This sets the speed of the movement of the tamp head

### TAMPING NUMBER

Set Tamper Number  
Default = 1x (Range 1x, 2x & 3x)

Setting how many times the head will lower and raise.



<https://bosetamper.com/>